



INE.#	OEM.#	Description
STDIO1	SM-04-VRF	Display Board
STDIO2	SM-04-UL	Step LCD Display Board
STDIO3	SM-04-VSD	DOT Matrix Indicator Display Board
STDIO4	SM-04-VL16/A	Hall Display Board
STDIO5	SM-04-VSC	Display Board
STDIO6	SM-04-VLB3	LCD Vertical Display Board
STDIO7	SM-04-HRC	DOT Matrix Indicator Display Board
STDIO8	SM-04-HRD	DOT Matrix Indicator Display Board
STDIO9	SM-04-HSC	DOT Matrix Indicator Display Board
STDIO10	SM-04-VRJ	DOT Matrix Indicator Display Board
STDIO11	SM-04-HREB	Super Large Screen Dot Matrix Display Board
STDIO12	SM-04-HREC	Super Large Screen Dot Matrix Display Board
STDIO13	SM-04-ND	Call Display Board
STDIO14	SM-04-V7	Super Thin Indicator Display Board
STDIO15	SM-04-VRH	Super Thin Indicator Display Board
STDIO16	SM-04-V7/B	16 Segment Indicator Display Board
STDIO17	SM-04-V7/C	16 Segment Indicator Display Board
STDIO18	SM-04-H7/A	Parallel Indicator Display Board
STDIO19	SM-04-H7/B	Parallel Indicator Display Board
STDIO20	SM-04-HR/G	Parallel Indicator Display Board
STDIO21	SM-04-HR/H	Parallel Indicator Display Board
STDIO22	SM-04-VS-E	Parallel Indicator Display Board

INE.#	OEM.#	Description
STPCB01	SM-01-F5021	Main Controller PC Board
STPCB02	SM.01PA/D	Main Controller PC Board
STPCB03	SM-01-CD/A	Main Controller PC Board
STPCB04	SM-01-DP-C	Main Controller PC Board
STPCB05	SM-01-HO/B	Home Hydraulic Controller PC Board
STPCB06	SM-01-HO/C	Home Hydraulic Controller PC Board
STPCB07	SM-02-D	Car Controller PC Board
STPCB08	SM-03-D	Command PC Board



STDIO11



STDIO12




STDIO13



STDIO14




STDIO15




STDIO16




STDIO17




STDIO18




STDIO19




STDIO20



STDIO21



STDIO22




STPCB01




STPCB02



STPCB03



STPCB04



STPCB05



STPCB06



STPCB07



STPCB08