

No	Name	Accessories	Number
A	Back panel		1
B	Left side		1
C	Right side		1
D	Door frame		1
E	Top panel		1
F	Bottom shelf		1
G	Middle wrist		1
H	Lower middle side		2
I	Upper middle side		2
J	Left clothes rail		4
K	Right clothes rail		2
L	Left clapboard		4
M	Right clapboard		2
N			
O	screw		40
P			

