# HBO<sup>®</sup> 103 W/2




#### Product description

- Mercury discharge lamp
- Short arc
- For DC operation at constant power
- High pressure during operation
- For vertical and horizontal operation

## Electrical Data and Lamp Geometry

Rated lamp power	W	100
Rated lamp current	А	4.44
Initial voltage range	V	17 25
Ignition voltage (cold)	V	850
Overall lamp length I1	mm	max. 90
Lamp length I <sub>2</sub>	mm	max. 82
Bulb diameter d	mm	10.0 ± 0.2
Length a <sup>1</sup>	mm	43.0 ± 1.5
Arc gap (cold)	mm	approx. 0.6
Base (anode side)		• SFa 9-2
Base (cathode side)		• SFa 7.5-2

## Performance Data<sup>2</sup>



Initial luminous flux	lm	min. 2550	
Initial light intensity <sup>3</sup>	cd	min. 270	
Declared service life 4	h	300	

Full luminous flux is generated after a run-up phase of approximately five minutes.

## Mounting

This lamp should be mounted at the anode base; the cathode base should be left unsupported. It is allowed to mount at the cathode base leaving the anode base unsupported; however, this renders length "a" meaningless.

<sup>2</sup> At rated power if not otherwise specified; data pertains to both vertical and horizontal operation.



<sup>&</sup>lt;sup>1</sup> Length "a" specifies the position of anode tip referring to reference plane at room temperature.

<sup>&</sup>lt;sup>3</sup> Light intensity in the plane containing anode tip and vertical to lamp axis

<sup>&</sup>lt;sup>4</sup> At switch cycle 2 hours on, 2 hours off

# HBO<sup>®</sup> 103 W/2

#### Operation Conditions

Burning position		s 90 (vertical-to-horizontal, anode down)		
Base temperature	C	max. 230 allowed		
Cooling		depending on lamp housing convection may be sufficient		
Arc stabilisation		not required		
Allowed power range <sup>5</sup>	W	70 125 (in case of short-time line voltage deviations)		
Required inrush current	Α	min. 5, max 8		
Polarity		for proper polarity observe base marking		

This lamp type can be operated both on a standard ballast and on an electronic power supply provided they comply with the requirements laid down in *Guidelines for Power Supplies and Igniters* (see table below).

#### Safety Instructions

- During operation the lamp has a very high internal pressure. Even so, an explosion is extremely unlikely but, the possibility cannot be entirely ruled out.
- HBO-Lamps must only be operated in purpose-built lamp housings which prevent direct viewing of the arc and in case of lamp bursting refrain lamp particles.

## Additional Documentation

Ti	tle	Order reference
٠	Typical Spectral Distribution	
٠	Mercury Safety Instructions for HBO Short Arc Lamps	No. FO 4574
٠	Guidelines for Power Supplies and Ignitors	No. FO GL-2

For the above mentioned publications contact an OSRAM representative in your neighbourhood.



<sup>&</sup>lt;sup>5</sup> It is recommended to operate this lamp with rated power.